







#### Standard Operating Procedures Scenario 3 Customer brings in USB Drive DATA DESTRUCTION





### Legal Indemnification



- This document explains the customers rights
- The customer enters the information and digitally signs the agreement before work begins
- The customer is emailed a copy automatically upon accepting the terms and clicking 'NEXT'



http://www.cprtools.net/omx/





### The Hardware

Introduction





### **XDR Kit**





1 – PSIClone



1 - SATA

Cable









1 – XDR Boot CD (for use on Apple)

1 - PATA**Plus Power** Cable

1 USB Cable

1 - AC Power Supply and cord



Boot/Log Thumb Drive

4





mls





### Customer brings in External USB Drive For DATA DESTRUCTION





# What you will need







1 – PSIClone

1 USB Cable



1 – OMX PC/Laptop





1 - XDR CD



1 – XDR USB Thumb Drive

6



### What it will look like



#### **Customer External Drive**



#### **External Drive XDR Setup**



Since the customer is only supplying the single USB hard drive, the PC in this scenario is supplied by OfficeMax







### Scenario 7 DESTRUCTION Steps





## **PSICIone Power**



#### Plug the Round Power Supply connector into the Power Supply connector on Side A of the PSIClone.









# Plug the USB connector into the USB slot on Side B of the PSIClone.









### 1. Insert XDR USB Thumb Drive into OMX PC

2. Insert USB cable from PSIClone into OMX PC



NOTE: The computer or laptop must be configured to boot from USB

Copyright CPR Tools 2012





# Press the **RED** power button to turn the PSIClone on.



#### It takes 10 - 30 seconds for PSIClone to power on to this screen







- Some computers may not be set to boot from anything but the internal hard drive
- In these cases you have to set the computer to boot from USB or CD
- To access the Boot Device Menu press the appropriate key when the computer is started
- Typical keys are: F12, F10, F8
- Select USB Storage Device or CD Rom as appropriate
- Power on computer







# **BIOS Settings**



- Some computers do not have the Boot Device Menu
- In these cases you have to set the BIOS to boot from USB or CD
- To access the BIOS press the correct key when computer is started common ones are:
  - Delete key
  - F2
  - F12
  - ESC
- The initial boot up screen should contain this information
- Select the boot sequence to boot from USB and CD first and second
- Power on computer





14



### **XDR Startup**



- Wait for the XDR Utility to boot up to the Startup screen (shown at right)
- Remove XDR USB Thumb Drive (If using CD to boot it will eject automatically)
- Click the 'Begin' button







### Customer Info



- Enter the required information
- Click the 'Start' button

, ,	KDR eXtreme Data Recovery		
Any OS Data ( All Data is Treat	ta Recovery Collection System ed as Confidential at all times		
Service Call Number	0001		
Employee Name	Agent Smith		
Customer Name	John Doe		
The start function will detec Further questions may be a You can press the EXIT butt Attach the client's Device t	ct the media that is attached to XDR. asked as the process proceeds to final data collection. on at any time to stop this process. o the PSIClone's 'A' side and click the START button.		
	Start	F	





# Choose Method



• Click "Erase drive"







### **Drive Scan**



- Select the customer drive to perform data destruction on (this is the USB hard drive)
- Click 'Continue'

XDR will perform a scan to ensure the data destruction can be performed on the drive



WARNING: Verify the customer drive model



### Select drive



- Type 'I Understand' exactly as shown
- Click 'Ok'

XDR eXtreme Data Recovery	
eXtreme Data Recovery	
Really Erase Entire Devi	ce?
You have indicated you wish to erase the VBOX_HARDDISK Har IDE0,1 with serial number VB6b0a67e9-c700f902.	d Drive on
WARNING! This will permanently erase ALL DATA on the select Do you REALLY want to erase this entire device?	ed device
If you wish to proceed please type "I Understand" and press 'Ol	<
l Understand	
Ok Cancel	





## Choose Method



• Click "Zero"









- Insert the XDR USB Thumb Drive back into computer
- Click "Rescan"
- Select the XDR USB thumb drive to be used for the logging information
- EXtreme Data Recovery

   Select a USB device for the XDR logfile: Ut161 USB2FlashStorage Hard Drive on USB0

   Device: Size Description

   IDE0.0 CD-ROM Drive
   VBOX\_CD-ROM

   VISB0 Hard Drive
   1.007.GB

   USB0 Hard Drive
   1.007.GB

   USB0 Hard Drive
   1.007.GB

   USB0 Hard Drive
   1.007.GB

   Back
   Continue

Click 'Continue'



- Verify this is the customer drive!
- Click 'Begin' to start



EXTREME DATA Recovery





# How long?



Once started, the percentage complete and estimated time remaining will be displayed







# Completed



Once the process has completed XDR will display the successful completion or a FAILURE.

If the drive fails there is nothing that can be done in store.





# Clean Up



- Remove XDR CD/USB Thumb drive from PC/Laptop
- 2. Remove PSIClone USB from PC/Laptop
- 3. Remove customer USB drive from PC
- Power down the PC/Laptop





# Lastly



- Invoice customer
- Return customer equipment





# Need Help?



- Visit Our Support Website
  - <u>http://www.cprtools.net/omx</u>
- Email
  - <u>omx@cprtools.net</u>
- Call
  - 1-863-674-0120
  - 10am 7pm
  - Mon-Fri

Hard Drive Recovery Services		Data Recovery Portable Device Services	
<ul> <li>PC/Laptop</li> <li>USB External Storage De</li> <li>FREE DIAGNOSTIC</li> </ul>	vices	Portable Flash Devices     FREE DIAGNOSTIC	
Basic	Advanced	Basic	Advanced
Uses Patented Technology Usually done in hours versus weeks Never leaves the store	Damaged storage devices (water, fire, droped, etc.)     Uses patented technology     Safely transported and recovered in our partner facilities: Over 25 years of data recovery experience Insured and Bonded company Secure facilities All employees background checked	Technology • Usually done in hours versus weeks • Never leaves the store	fire, imsahed, etc.) Uses patented technology Safety transported and recovered in our partner facilities: Over 25 years of data recovery experience Insured and Bonded company Secure facilities All employees background checked
Data Transfer	Hard Drive Data Fradi	cation Dat	a Recovery Service Plan
Seamless PC Upgrades     Audit Trail and Certification		1000	a the story connect han

27